

HONDA ENGINE GEAR CHART

	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
23	5.31	5.11	4.93	4.76	4.60	4.45	4.31	4.18	4.06	3.94	3.83	3.73	3.63	3.54	3.45
24	5.54	5.33	5.14	4.97	4.80	4.65	4.50	4.36	4.24	4.11	4.00	3.89	3.79	3.69	3.60
25	5.77	5.56	5.36	5.17	5.00	4.84	4.69	4.55	4.41	4.29	4.17	4.05	3.95	3.85	3.75
26	6.00	5.78	5.57	5.38	5.20	5.03	4.88	4.73	4.59	4.46	4.33	4.22	4.11	4.00	3.90
27	6.23	6.00	5.79	5.59	5.40	5.23	5.06	4.91	4.76	4.63	4.50	4.38	4.26	4.15	4.05
28	6.46	6.22	6.00	5.79	5.60	5.42	5.25	5.09	4.94	4.80	4.67	4.54	4.42	4.31	4.20
29	6.69	6.44	6.21	6.00	5.80	5.61	5.44	5.27	5.12	4.97	4.83	4.70	4.58	4.46	4.35
30	6.92	6.67	6.43	6.21	6.00	5.81	5.63	5.45	5.29	5.14	5.00	4.86	4.74	4.62	4.50
31	7.15	6.89	6.64	6.41	6.20	6.00	5.81	5.64	5.47	5.31	5.17	5.03	4.89	4.77	4.65
32	7.38	7.11	6.86	6.62	6.40	6.19	6.00	5.82	5.65	5.49	5.33	5.19	5.05	4.92	4.80
33	7.62	7.33	7.07	6.83	6.60	6.39	6.19	6.00	5.82	5.66	5.50	5.35	5.21	5.08	4.95
34	7.85	7.56	7.29	7.03	6.80	6.58	6.38	6.18	6.00	5.83	5.67	5.51	5.37	5.23	5.10
35	8.08	7.78	7.50	7.24	7.00	6.77	6.56	6.36	6.18	6.00	5.83	5.68	5.53	5.38	5.25

RPM Wanted ÷ RPM Ran x Gear Ratio Ran = New Gear Ratio Needed

Example: **5480** ÷ **5220** x **4.97** = **5.22**

RPM Wanted: **5480**

Current Ratio In Car:

4.97

RPM Ran: **5220**

New Gear Ratio Needed To Reach 5480:

5.22